


# Bally hand control

12-29-81

Viewed from end of plug



*Sprysteen*

- red - trigger
- green - JX right (JX = +1)
- white - JX left (JX = -1)
- \* blue - JY up (JY = +1)
- black - knob (potentiometer)
- yellow - common to trigger and joystick
- brown - knob (potentiometer)
- \* orange - JY down (JY = -1)

## Bally Basic Interface

Plug to hand control No. 3 from the interface is using only 3 wires to 3 plug pins: black, yellow and orange

Steve Walters sent this to me but the functions of the orange + blue wires are switched from the diagram in the Bally Basic instruction manual (Pg. 100). Which is correct?